

Front Spars

Categories : [Wing Construction](#)

Date : February 23, 2016

Made the clamp wedges and a front spart in the jig ready for T88 epoxy.

